

These assembly instructions apply to:



VAC 6  
VAC 8  
VAC 10  
VAC 11  
VAC 12

VAC 13  
VAC 15  
VAC 20  
VAC 30  
VAC 40

Series VAC TWIN



## Contents

---

<b>1</b>	<b>General information</b>	<b>3</b>
<b>2</b>	<b>Safety</b>	<b>5</b>
<b>3</b>	<b>Technical data</b>	<b>8</b>
<b>4</b>	<b>Design and function</b>	<b>13</b>
<b>5</b>	<b>Transport and storage</b>	<b>15</b>
<b>6</b>	<b>Installation</b>	<b>16</b>
<b>7</b>	<b>Start-up and operation</b>	<b>23</b>
<b>8</b>	<b>Maintenance and servicing</b>	<b>24</b>
<b>9</b>	<b>Troubleshooting</b>	<b>25</b>
<b>10</b>	<b>Spare parts and accessories</b>	<b>26</b>
<b>11</b>	<b>Disposal</b>	<b>27</b>
<b>12</b>	<b>Annex</b>	<b>28</b>

<b>Scope of delivery</b>	Please refer to the delivery note for the scope of delivery. Check the packaging for possible transport damage. In the event of damage to the packaging, check the contents for completeness and possible damage. Inform the carrier in the case of damage.	
<b>Designation</b>	The vacuum mounts of the series VAC are hereafter referred to as "VAC".	
<b>Version of document</b>	Document no.	1555
	Version no.	2
	Date of issue	Dec. 2020

## 1 General information


<b>Use and storage</b>	Before installing the VAC read these instructions carefully. It is the basis for any action when dealing with the VAC, and may be used for training purposes. The instructions should be subsequently stored at the operation site.
<b>Target group</b>	The target group for these instructions is technical staff, who have basic knowledge in pneumatics and mechanics. Only complying technical staff may work on the VAC. The VAC may only be installed, put into operation, maintained, troubleshot and disassembled by persons authorised by the operator.
<b>Copyright</b>	This documentation is protected by copyright. <i>NetterVibration</i> reserves all rights such as translations, reprinting and reproduction of the instructions, as well as parts thereof.
<b>Limitation of liability</b>	All technical information, data and instructions for installation, operation and maintenance in these instructions are based on the latest information available at the time of printing and take our past experience to the best of our knowledge into account. No claims can be derived from the information, illustrations and descriptions in these operating instructions. The manufacturer does not assume liability for damages resulting from: <ul style="list-style-type: none"><li>• failure to observe the instructions,</li><li>• improper use,</li><li>• unauthorised repairs,</li><li>• technical modifications,</li><li>• use of non-permissible spare parts.</li></ul> Translations are made to the best of our knowledge. <i>NetterVibration</i> does not assume liability for translation errors, even if the translation was made by us or on our behalf. Only the original German text remains binding.
<b>Directives / standards observed</b>	The vacuum mounts of the series VAC comply with the EC Machinery Directive 2006/42/EC. In particular, the standard EN ISO 12100 has been observed.


**Instruction and warning symbols**

The following instruction and warning symbols are used in these instructions:

**Personal injuries**

<b>⚠ DANGER</b>	
	<p>indicates an immediate danger. Disregard of this notice will result in death or severe personal injuries.</p>

<b>⚠ WARNING</b>	
	<p>indicates a potential danger. Disregard of this notice can result in death or severe personal injuries.</p>


<b>⚠ CAUTION</b>	
	<p>indicates a potentially dangerous situation. Disregard of this notice can result in minor or moderate personal injuries.</p>

**Material damages**

<b>NOTICE</b>	
<p>indicates potential material damage. Disregard of this notice can result in material damage.</p>	

**Notes**

<b>IMPORTANT</b>	
<p>indicates actions, methods or notes that are not relative to safety, e.g. useful information and tips.</p>	

	<p><b>Environmentally safe disposal</b> indicates the obligation of environmentally safe disposal.</p>
---	--

## 2 Safety

### Intended use

The VAC are used for quick attachment of vibrators to smooth or, within limitation, convex surfaces. Among other applications, the VAC can be used in combination with vibrators for emptying transport containers or cleaning tubes and hoppers.

The VAC are used where there are otherwise no conventional mounting options for vibrators, where frequent relocation is necessary and where welding or screwing is not possible.

VAC can also be used outdoors as well as in dump environments. The VAC may not be submerged in bulk materials or in liquids.

Any other use is considered improper.

### Qualification of qualified personnel

Installation, commissioning, maintenance and troubleshooting of the VAC may only be performed by authorised qualified personnel.

All handling of the VAC is the responsibility of the operator.

### Falling parts

#### **WARNING**

#### **Falling parts**

The VAC can come loose with small component cross sections and in the event of an unexpected pressure drop.

The vibrators screwed to the VAC can be loosened by vibration

Pneumatic vibrators at full power can cause the VAC to slide.


Falling parts can cause severe personal injuries.

- All VAC except VAC 8 and VAC 10 are equipped with an adjustable safety cable. Choose a secure attachment point (such as an eye) for the safety cable on the container or system. Adjust the cable with the cable clamps as short as possible so that the VAC can never fall into a loose cable.
- VAC 8 and VAC 10 have to be secured against dropping down by the customer.
- If you attach the VAC to round components, then the specified minimum diameters given in Ch. Technical data (cf. page 8; "Parameters") must be observed.
- For the first start-up, set the frequency of the vibrator by means of a throttle check valve (e.g. on the hose set HG ... with DRV) so that sliding of the VAC is prevented.

**Compressed air**

<b>⚠ WARNING</b>	
<b>Compressed air</b>	
A loosened hose which is under pressure can lead to personal injuries.	
<ul style="list-style-type: none"> <li>➤ Screw the hose lines on carefully.</li> <li>➤ Check the hose lines and connections after one hour of operation and thereafter regularly (generally monthly).</li> <li>➤ Retighten the hose lines, if necessary.</li> <li>➤ Ensure that the compressed air is disconnected from the supply lines during all work on the VAC.</li> <li>➤ Prevent the VAC from being switched back on during all work.</li> </ul>	

**Sound level**

<b>⚠ WARNING</b>	
	<p><b>Sound level</b></p> <p>Depending on the VAC and vibrator used, the sound pressure level may exceed 80 dB(A) in the vicinity of the constructions connected to the VAC. The human ear can be permanently damaged by the high sound level.</p> <ul style="list-style-type: none"> <li>➤ When working in the noise area, use ear protection if 80 dB(A) is exceeded.</li> <li>➤ Depending on the design and combination of VAC and vibrator, take additional noise protection measures.</li> </ul>

**Heavy parts**

<b>⚠ WARNING</b>	
<b>Risk of injury while handling heavy parts</b>	
Risk of serious injury due to weight during transport and installation of the VAC.	
<ul style="list-style-type: none"> <li>➤ Observe the weight information in Chapter Technical data, from page 8 on.</li> <li>➤ Only qualified personnel may transport and install the VAC.</li> <li>➤ Use suitable load handling devices and slinging equipment.</li> <li>➤ Wear suitable personal protective equipment.</li> </ul>	

**Combination VAC and vibrator**

<b>NOTICE</b>	
<p>Only use approved combinations of VAC and vibrator. The applicable vibrators can be found in Ch. Technical data, page 9.</p> <p>When using other vibrators, the operator is responsible for checking safety and functionality.</p>	



**Assembly**

**NOTICE**

If VAC and vibrator are ordered separately, the vibrator must first be mounted on the VAC, then the VAC on the container.

**Silencer**

**NOTICE**

Operation of the VAC with silencers is mandatory.  
Silencers reduce the noise level and protect the VAC from contamination entering.

**Clean surface**

**NOTICE**

The VAC may only be operated on clean and dustless surfaces free from grease.

**Fastening of vibrator**

**IMPORTANT**

Information on secure fastening of the vibrator can be found in the corresponding operating instructions.

### 3 Technical data

**Permissible operating conditions**

Drive medium	The VAC must be operated with filtered compressed air (filter $\leq 5 \mu\text{m}$ ). Further drive medium requirements to be respected can be found in the operating instructions of the mounted vibrator.
Lubrication	The VAC do not need lubrication.
Ambient temperature	-10 °C to +60 °C
Operating pressure	2 to 6 bar

**Parameters**

Type: VAC ... + HG ...	Vacuum generated [bar]		Suction generated [N]		Weight [kg]	Air consumption [l/min]		Sound pressure level* [dB(A)]		Min.- Ø for round containers [mm]
	4 bar	6 bar	4 bar	6 bar		4 bar	6 bar	4 bar	6 bar	
6 + 6 N	0.8	0.8	350	350	0,53	6.5	10	72	76	400
8 + 10 N	0.60	0.85	340	481	0.95	40	60	72	72	110
8 + 10 S	0.60	0.85	340	481	1.20	20	22	72	72	110
10 + 10 N	0.60	0.85	465	658	1.05	40	60	72	72	110
10 + 10 S	0.60	0.85	465	658	1.30	20	22	72	72	110
11 + 10 N	0.60	0.85	710	1,005	1.25	40	60	72	72	110
11 + 10 S	0.60	0.85	710	1,005	1.50	20	22	72	72	110
12 + 15 N	0.60	0.85	1,250	1,770	2.85	60	122	74	74	350
12 + 15 S	0.60	0.85	1,250	1,770	3.20	29	36	74	74	350
13 + 15 N	0.60	0.85	1,362	1,930	4.20	110	170	83	77	850
13 + 15 S	0.60	0.85	1,362	1,930	4.55	41	52	83	77	850
15 + 15 N	0.60	0.85	1,476	2,091	3.40	110	170	74	74	650
15 + 15 S	0.60	0.85	1,476	2,091	3.75	41	52	74	74	650
20 + 15 N	0.60	0.85	2,724	3,859	7.25	110	170	74	74	850
20 + 15 S	0.60	0.85	2,724	3,859	7.60	41	52	74	74	850
30 + 30 N	0.60	0.85	4,086	5,789	11.50	110	170	74	74	1,500
30 + 30 S	0.60	0.85	4,086	5,789	12.00	49	60	74	74	1,500
40 + 40 N	0.60	0.85	5,448	7,718	20.00	220	340	74	74	1,500

\* The sound pressure level was measured at a distance of 1 m without vibrator. The sound pressure levels of the vibrators are often higher.

For information on the VAC TWIN, please refer to the supplement to operating instructions for VAC TWIN / VAC TWIN GD.

**Service life**

The technical performance data changes over the service life (wear and contamination).



**Approved combinations of VAC and vibrator**

Type	Applicable vibrators						
	NCB	NCR	NCT	NTK	NTP	NTS	PKL
VAC 6	-	-	1, 2	-	18	80 - 180 (HF, NF)	-
VAC 8	1, 2	-	1, 2	8 AL	25*	120 (HF, NF), 180 (HF, NF)	-
VAC 10, VAC 8 TWIN***	1, 2, 3	3	3, 4	15 X, 16, 18 AL	25*	120 - 250 (HF, NF)	190*
VAC 11	3, 5	10	5, 10	18 AL	-	180 (HF, NF), 250 (HF, NF)	190*, 450*
VAC 12, VAC 8 / 10 TWIN***	10, 20	22	15, 29	25 AL	25*, 32*, 48*	350 (HF, NF), 100/01, 75/01*, 50/01*	450*, 740*, 1000*
VAC 13, VAC 12 TWIN***	10, 20	22	15, 29	-	32*, 48	75/01, 50/01, 70/02	740**, 1000, 2100, 5000
VAC 15	10, 20, 50, 70	22, 57	15, 29, 55, 108	18 AL, 25	32, 48	250 (HF, NF), 350 (HF, NF), 75/01, 50/01, 70/02	740**
VAC 20	-	57	55, 108	-	32, 48	70/02, 54/02, 50/04	2100, 5000
VAC 30	-	120	126, 250	-	-	50/04, 50/08	5000
VAC 40	-	-	-	-	-	50/08, 50/10	-

\* adapter plate necessary, not included in delivery

\*\* adapter plate or insert EE required

\*\*\* NetterVibration has to be consulted

**NOTICE**

Not every pneumatic vibrator may be screwed onto the VAC. Damage to the internal control bores is possible with drilling patterns other than the templates (see Ch. Installation, from page 17 on). The above combinations of VAC and vibrator are tested and can be used without restrictions except those marked with \*/\*\*.

When using other vibrators, the operator is responsible for checking safety and functionality.

**Hose sets to be used**

Depending on the vibrator used, the VAC ought to be used with the following hose sets:

Vibrator: PKL	Other vibrators
Hose set HG 10 N or HG 10 S	Combinations of VAC and hose set mentioned under "Parameters" (see page 8, column Type VAC ... + HG ...)


**Grommets / hoses**

*NetterVibration* recommends the following cross sections for grommets and hoses:

Type	Hose grommet [inch]	Hose size to the VAC*	Hose size to the vibrator*
VAC 6	1/8	DN 4	DN 4
VAC 8, VAC 10, VAC 11	1/4	DN 6	DN 6
VAC 12, VAC 13, VAC 15, VAC 20	3/8	DN 6	DN 9
VAC 30, VAC 40	1/2	DN 9	DN 12

\* DN= nominal diameter


**Dimensions VAC 6 - 13**



Type: VAC ...	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]
6	33.5	15	100	68	-	-
8	19	8	150	127	30	55
10	22	8	200	175	26.5	55
11	20	5.5	300	276	26	55
12	25	10	300	268	68	100
13	70	30	200	186	-	-

Dimension X depending on the vibrator


**Dimensions  
VAC 15 / 20**



Type: VAC ...	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]
15	56	25	350	290	100	150
20	70	30	430	370	150	200

Dimension X depending on the vibrator

**Dimensions  
VAC 30 / 40**



Type: VAC ...	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]
30	70	30	396	337.5	426	370
40	70	30	430	370	375	425

Dimension X depending on the vibrator

**Tightening torques**


*NetterVibration* recommends the following tightening torques for fastening screws and nuts of the quality 8.8 (coefficient of sliding friction 0.14):

	M4	M5	M6	M8	M10	M12	M16	M20	M22	M24	M30
Tightening torque [Nm]	3	6	10	25	50	87	210	411	559	711	1,422
Minimum screw depth [mm] for tapped hole in S 235 JR*	7	8	10	13	17	20	27	34	37	40	50

\* Material S 235 JR = St 37-2, minimum screw depth for other materials on request

## 4 Design and function

### Design



- |   |                               |   |               |
|---|-------------------------------|---|---------------|
| 1 | Ground plate with suction cup | 4 | Vacuum nozzle |
| 2 | Hose set connection           | 5 | Silencer      |
| 3 | 2/2-way ball valve            | 6 | Vibrator      |

### Function

VAC mainly consist of a ground plate with suction cup(s) (1), a 2/2-way ball valve (3) and a vacuum nozzle (4). By actuating the 2/2-way valve (3) a vacuum is generated with the vacuum nozzle (4). As a result, the VAC attaches itself with the suction cup(s) (1) to the mounting surface.

### Hose set HG N with DRV




- |   |                            |
|---|----------------------------|
| 1 | Vibrator connection        |
| 2 | Throttle check valve (DRV) |
| 3 | 3/2-way manual slide valve |
| 4 | Compressed air connection  |
| 5 | VAC connection             |

When the compressed air supply line is open, the VAC is permanently supplied with compressed air through the hose set.

The vibrator is switched on and off by actuating the 3/2-way manual slide valve (3).

The hose set HG ... N with DRV is equipped with a throttle check valve (2). By using the throttle check valve, it is possible to set the pressure applied to the vibrator and thereby the frequency of the vibrator.

**Hose set HG S  
with DRV**



- 1 Vibrator connection
- 2 Throttle check valve (DRV)
- 3 3/2-way manual slide valve
- 4 Compressed air connection
- 5 Throttle screw (air-saving function)
- 6 Throttle valve
- 7 VAC connection

In addition to the standard version N the hose set HG ... S has an economy switch position. With the vibrator switched off the compressed air consumption can be reduced by approx. 30 % in comparison to the standard version by means of a throttle screw (5). This compressed air reduction is possible, because the "holding function" does not require the totally available compressed air. For operating the vibrator, the totally available compressed air is needed and released by the hose set HG ... S.

## 5 Transport and storage




Observe the safety instructions in Ch. Safety, from page 5 on.

### Transport conditions

Special conditions of transport are not required.

### Lifting VAC 40

Due to its own weight, the VAC 40 may only be lifted with a suitable load handling device. In case it has to be lifted, the VAC 40 is equipped with an M16 eye bolt.



### Packaging

The VAC are packed and ready for assembly. VAC together with hose set and vibrator are delivered completely, unless otherwise agreed.

The packaging protects the VAC from transport damage. The packaging material has been selected from an environmentally safe and technically disposable point of view and is therefore recyclable.

The return of packaging to the material cycle conserves raw materials and reduces the amount of waste.

### Storage conditions

- Store the VAC in a dry and clean environment.
- Protect the VAC from UV-exposures, weather and ozone.
- The storage temperature is between -20 °C and +60 °C.
- Close all openings when re-storing.
- Replace aged, brittle suction cups before renewed start-up.

## 6 Installation



Observe the safety instructions in Ch. Safety, from page 5 on.

**Technical data** Information on tightening torques for screws and cross-sections for hoses can be found in Ch. Technical data, from page 8 on.

**Procedure** When installing the VAC, carry out the following steps in succession:


**Adapter plate**

IMPORTANT


Some vibrators require an adapter plate for mounting on certain types of VAC (see Ch. Technical data, page 9).

Adapter plates with matching bores are available on request.

**VAC 6** Mount the approved vibrator as follows:



Example: NTS




Example: NTP

- 1 Suction cup
- 2 Ground plate of VAC
- 3 Vibrator
- G Setscrew
- S Hexagon bolt

1. Determine and mark the required bores using the following template. Common hole spacings are marked.
2. Drill tapped blind holes from above into the ground plate (2). The diameter of the through-holes (x) that is necessary for the vibrator can be found in the table for the template.
3. Mount the vibrator (3) with setscrews according to DIN 913 (G; for NTS) or hexagon bolts according to DIN 933 (S; for NTP and NCT). Use suitable screw lockings.



Template for bores VAC 6




Thread	Vibrator : dimension [mm]
M10	NTS 180
M8	NTS 120
M6	NCT (1, 2) : 56
M5	NTS 80
	NTP 18 : 43

**Note:** The grey marked area may not be drilled.

- VAC 8
- VAC 10
- VAC 11
- VAC 12


There are the following options for screwing the approved vibrator on the retaining/adapter plate of the VAC:



**Options A and B:**

1. Screw the vibrator (1) onto the retaining/adapter plate (x).
2. Attach the adapter plate on the VAC as follows:

Option A	Option B
Drill two tapped blind holes from above into the ground plate (2). Make sure that the suction cup (3) is not perforated.	Drill through the suction cup (3) and the ground plate (2) from below. Countersink the bores. For a vacuum to build up, each countersunk screw must be sealed with an O-ring (4).


Option C	
	<p>Drill through the suction cup (3) and the ground plate (2) from below.</p> <p>Screw each countersunk screw with an O-ring from below into the ground plate and the adapter plate (x) so that the screw is flush with the adapter plate and do not protrude.</p> <p>Then screw the vibrator (1) onto the retaining/adapter plate (x). Use suitable screw lockings.</p>

**Vibrator thread size**

- VAC 13
- VAC 15
- VAC 20
- VAC 30
- VAC 40

The thread size of the vibrator can be found in the corresponding operating instructions.

Mount the approved vibrator as follows:




- 1 Suction cup
- 2 Ground plate of VAC
- 3 Vibrator (flange/base plate)

1. Unscrew the suction cups (1) of the VAC.
2. Determine and mark the required bores using the following templates. Common hole spacings are marked.
3. Drill through-holes. Countersink the bores according to DIN74BFx on the suction cup side of the ground plate (2). The diameter of the through-holes for the vibrator can be found in the table for the corresponding template.
4. Mount the vibrator (3) with the designated countersunk screws with the hexagon socket according to EN ISO 10642. Use suitable screw lockings.
5. Mount the suction cups in the correct position.

**Adapter plate or EE insert**

IMPORTANT
An adapter plate is required for mounting the PKL 740 on the VAC 13 or the VAC 15, unless the EE insert is used.


Template for bores VAC 13



Ø bores [mm] (thread)	Vibrator : dimension [mm]
17 (M16)	PKL 5000 : Ø152
13 (M12)	NTP 48 : 78x78
	PKL 740 : 100x50
	PKL 1000 : Ø116
	PKL 2100 : Ø152
11 (M10)	NTP 32 : 51x51
9 (M8)	NCB (10, 20), NCR 22, NCT (15, 29) : 104
	NTS (75/01, 50/01) : 72x72
	NTS 70/02 : 90x90

**Note:** The grey marked area may not be drilled.

Template for bores VAC 15




**Note:** The grey marked area may not be drilled.

Ø bores [mm] (thread)	Vibrator : dimension [mm]	
17 (M16)	NTK 25	
13 (M12)	NTP 48 : 78x78	NCB (50, 70), NCR 57, NCT (55, 108) : 130
	NTS (250, 350)	PKL 740 : 100x50
11 (M10)	NTK 18 AL	NTP 32 : 51x51    NTS 70/02 : Ø51*
9 (M8)	NTS (75/01, 50/01) : 72x72	NCB (10, 20), NCR 22, NCT (15, 29) : 104

\* when using a round base plate

Template for bores VAC 20




**Note:** The grey marked area may not be drilled.

Ø bores [mm] (thread)	Vibrator : dimension [mm]	
17 (M16)	PKL 5000 : Ø152	
13 (M12)	NTP 48 : 78x78	PKL 2100 : Ø152
	NCR 57, NCT (55, 108) : 130	NTS 50/04 : 124x124
11 (M10)	NTP 32 : 51x51	
9 (M8)	NTS (54/02, 70/02) : 90x90	NTS 70/02 : Ø51*

\* when using a round base plate

Template for bores VAC 30




**Note:** The grey marked area may not be drilled.

Ø bores [mm] (thread)	Vibrator : dimension [mm]		
17 (M16)	NCR 120, NCT (126, 250) : 152	NTS 50/08 : 165x165	PKL 5000 : Ø152
13 (M12)	NTS 50/04 : 124x124		


**Bores VAC 40** The VAC 40 consists of two VAC 20 and an adapter plate. The adapter plate is delivered with the through-holes necessary for the installation of the vibrator.

**Standard installation with hose set HG ... N with DRV**



- 1 3/2-way valve
- 2 Non-return throttle valve
- 3 Vibrator
- 4 Vacuum nozzle
- 5 Suction cup
- 6 2/2-way ball valve
- v VAC

**Standard installation with hose set HG ... S with DRV**



- 1 3/2-way valve
- 2 Non-return throttle valve
- 3 Vibrator
- 4 Vacuum nozzle
- 5 Suction cup
- 6 2/2-way ball valve
- 7 Non-return valve
- 8 Throttle valve
- v VAC

**Air supply**

The loss of pressure increases with hose length. The nominal diameters in Ch. Technical data, from page 8 on, apply to hose lengths up to 3 m. Longer supply lines require larger cross-sections.

**Air discharge**

From the two outgoing hoses of the hose set, connect

- the hose, which is always under pressure, to the VAC and
- the detachable hose to the vibrator.



**Checklist  
installation**

Check that the following steps have been carried out:

- Compliance with permissible ambient temperatures ensured?
- Mounting surface clean?
- Vibrator and hose set mounted?
- Screw size and tightening torques observed?
- Fastening screws secured with liquid safety agent, if necessary?
- VAC and vibrator connected according to circuit diagram?
- Compressed air supply line fastened securely?
- Hose supply connection sealed with liquid sealant, if necessary?
- Specifications on kind of hose, hose length and nominal width observed?
- Function of VAC checked?
- VAC secured against falling by means of the safety cable?

## 7 Start-up and operation



**Observe the safety instructions in Ch. Safety, from page 5 on.**

### Permissible operating conditions

Please refer to Ch. Technical data, page 8 for permissible operating conditions.

### Procedure

When starting-up the VAC carry out the following steps in succession:

1. Switch on the compressed air to supply the VAC and the vibrator.
2. Position the VAC at the desired location and activate the 2/2-way ball valve on the VAC to generate the vacuum required under the suction cup.
3. Check the VAC for tightness. If the VAC can be loosened by hand,
  - check the mounting surface for unevenness and contamination,
  - control and, if necessary, increase the pressure (e.g. with a maintenance unit with pressure regulator).
4. Start the vibrator with the 3/2-way manual slide valve on the hose set.
5. Set the frequency of the vibrator by means of a throttle check valve (e.g. on the hose set HG ... with DRV) so that sliding of the VAC is prevented.

### Checklist start-up

Check that the following steps have been carried out:

Hose connections checked before installation?

Desired frequency set?

The maximum permissible frequency must not be exceeded.

After 30 minutes of operating time:

Frequency still as set?

If necessary, adjust frequency.

After one hour of operating time:

Hose supply lines and fastening screws checked, retightened if necessary?

Then abide to the maintenance plan.

## 8 Maintenance and servicing



Observe the safety instructions in Ch. Safety, from page 5 on.

### Maintenance plan

Maintenance of the VAC must be carried out as follows:

Interval	Action
After an hour of operation after initial start-up	Check fastening screws, retighten if necessary.
	Check hose screw connections and hose fittings, retighten if necessary.
Monthly	Check fastening screws, retighten if necessary.
	Check hose screw connections and hose connections and retighten, if necessary.
	Check hose supply lines for permeability and kinking. If necessary, clean and remove kinks.
	Check the function of the silencer. Clean silencer.
	Check the frequency of the vibrator and set, if necessary.
	Check suction cups for wear. Replace aged, brittle suction cups.
	Check vacuum nozzle for airflow. In case of clogging, the nozzle of the VAC 8 / 10 / 11 / 12 must be disassembled and cleaned. On all other types, disassembly and cleaning of the vacuum nozzle may only be performed by <b>NetterVibration</b> .
Check safety cable.	

Observe the maintenance instructions of the vibrator.

### Maintenance intervals

The maintenance intervals depend essentially on the service life and how clean the drive medium is.

Unfiltered compressed air leads to high wear, silencer clogging or complete failure of the VAC.



## 9 Troubleshooting

### Malfunctions and causes

In the case of malfunctions of the VAC proceed as follows:

Malfunction	Possible causes	Corrective actions
VAC does not generate vacuum	Air supply insufficient	Check pressure before VAC and set to 2 to 6 bar.
	Hose connections not correctly assembled	Check the hose connection assembly.
	Lines kinked	Lay lines without kinking.
	Cross-section of supply line insufficient	Increase cross-section of supply line.
	Silencer clogged	Clean or replace silencer.
	Vacuum nozzle clogged	Clean vacuum nozzle (let clean; see page 24, "maintenance plan").
	Mounting surface permeable to air or rough	VAC is not suitable for this application.
VAC slides when vibrated	Air supply insufficient	Check pressure before VAC and set to 2 to 6 bar.
	Lines kinked	Lay lines without kinking.
	Silencer clogged	Clean or replace silencer.
	Vacuum nozzle clogged	Clean vacuum nozzle (let clean; see page 24, "maintenance plan").
	Mounting surface permeable to air	VAC is not suitable for this application.
	Mounting surface oily, greasy or moist	Remove relevant layers.
	Suction cups worn	Replace aged, brittle suction cups.
	Subsurface reinforced (bounce impacts)	Put VAC on elastic surface between reinforcements (membrane effect).
	Vibrational frequency too high	Set frequency with a non-return throttle valve.

## 10 Spare parts and accessories

### Ordering of spare parts

Please provide the following details when ordering spare parts:

- required amount
- description and position of spare part
- type of VAC

### Possible accessories

The following accessories are available for the VAC:

Accessory	Description
Hose material and hose screw connections	For air supply, available in various qualities and dimensions
3/2- or 2/2-way valves	For electrical, pneumatic, manual activation
Non-return throttle valves	For frequency regulation, manually adjustable or pneumatically controllable
Maintenance units	Filter regulator unit NFR for mounting with oil-free vibrators, maintenance unit NWE (filter regulator unit with lubricator) for mounting with lubricated vibrators
Netter Electronic Timers	Electric or pneumatic, for interval operation


### Special models

The following special models are available on request:

- other materials (e.g. silicone suction cups, stainless steel plates)

## 11 Disposal

### Prices

	All parts of the VAC must be properly disposed of according to the material specifications. The valid disposal prices of the VAC are available on request.
---	--

### Material-specifications

All parts of the VAC can be recycled.

Material	VAC 6	VAC 8 / 10 / 11 / 12	VAC 13 / 15 / 20 / 30 / 40
Steel	Safety cable, fastening screws	Ground plate, safety cable, fastening screws	Safety cable, fastening screws
Aluminium	Ground plate	Vacuum nozzle, hose screw connection	Ground plate, handle, hose screw connection
Brass, nickle-plated	Screw connections	Screw connections	Screw connections, vacuum nozzle
Plastics	Vacuum nozzle, suction cup	Suction cup, seal rings	Suction cups, seal rings

## 12 Annex




Declaration of Conformity for  
vacuum mounts

Nov. 2020  
No. 4902



Declaration of Conformity  
according to the  
EC Machinery Directive 2006/42/EC

We hereby declare that the **vacuum mounts of the series VAC**,  
equipped with the following vibrators,

VAC 6	NCT 1 - 2, NTP 18, NTS 80 - 180 (HF, NF)
VAC 8	NCB 1 - 2, NCT 1 - 2, NTK 8 AL, NTP 25, NTS 120 -180 (HF, NF)
VAC 10, VAC 8 TWIN	NCB 1 - 3, NCR 3, NCT 3 - 4, NTK 15 X, NTK 16, NTK 18 AL, NTP 25, NTS 120 - 250 (HF, NF), PKL 190
VAC 11	NCB 3 - 5, NCR 10, NCT 5 - 10, NTK 18 AL, NTS 180-250 (HF, NF), PKL 190, PKL 450
VAC 12, VAC 8 / 10 TWIN	NCB 10 - 20, NCR 22, NCT 15 - 29, NTK 25 AL, NTP 25, NTP 32, NTP 48, NTS 350 (HF, NF), NTS 100/01, NTS 75/01, NTS 50/01, PKL 450, PKL 740, PKL 1000
VAC 13, VAC 12 TWIN	NCB 10 - 20, NCR 22, NCT 15 - 29, NTP 32, NTP 48, NTS 75/01, NTS 50/01, NTS 70/02, PKL 740, PKL 1000, PKL 2100, PKL 5000
VAC 15	NCB 10 - 70, NCR 22 - 57, NCT 15 - 108, NTK 18 AL, NTK 25, NTP 32, NTP 48, NTS 250-350 (HF, NF), NTS 75/01, NTS 50/01, NTS 70/02, PKL 740
VAC 20	NCR 57, NCT 55 - 108, NTP 32, NTP 48, NTS 70/02, NTS 54/02, NTS 50/04, PKL 740, PKL 2100, PKL 5000
VAC 30	NCR 120, NCT 126 - 250, NTS 50/04, NTS 50/08, PKL 5000
VAC 40	NTS 50/08, NTS 50/10

comply with the above Machinery Directive.

A VAC consists of a base plate with suction cup(s), a 2/2-way ball valve and a vacuum nozzle.  
When the 2/2-way valve is actuated, the VAC attaches itself with the suction cup(s) to the mount-  
ing surface. The vibrator is firmly screwed onto the VAC.

Used harmonised standards are: **EN ISO 12100:2011**

The technical documentation is compiled in accordance with part A of annex VII. In accordance  
with annex II digit 1 part A. No. 2, **Netter GmbH, Germany** is authorised to establish the tech-  
nical documents .

Mainz-Kastel, 24.11.2020

p. p.



J. Gauß  
(Technical manager)

Netter GmbH • Fritz-Lenges-Str. 3 • 55252 Mainz-Kastel

Germany • Switzerland • Poland • Spain • Australia

[www.NetterVibration.com](http://www.NetterVibration.com)

Serving industry with vibration